


START

Ready for Recording or ON AIR

LIN/MIC Input 1/2 Stereo Mode
HP Level at 50%
DIGITAL OUT/USB Level at 75%

press both buttons
until the LED is off



HP Level (default)

HP rais / DO reduce
Range 32dB in 1dB steps

Change the DO/USB Level

LED flashes slow

Hold the DO button and press the HP button once.
With the same action back to HP Level


DO/USB Level

HP rais / DO reduce
Range 63dB in 1dB steps

HP button raise the level
holding the button raise continuously
the last shot will be saved

LED shows all actions

DO button reduce the level
holding the button reduce continuously
the last shot will be saved



HP on/off (N-1)

Inputs switched on/off from the Headphone

Hold the HP button and press the DO button once.
With the same action back

MONO

LED is on

Input 1 is the Mono Input on Headphone L / R

Hold the DO button and press the HP Button twice.
With the same action back

REF

LED flashes fast

1kHz -9dBFS on USB and Digital Out

Hold the DO button and press the HP button 3 times.
With the same action back

LED shows all actions

